

Directions for use



• Button

• Cup body

• Top cap

• TYPE - C charging port

① Please charge full the product with electricity before using



All the white lights flashing when charging, When electricity is full, the white light is always bright

② Add lubricant



Open the cover
Apply lubricant to the tank

③ Open to use



BURST KEY

In work, tap to enter Burst Mode 9, Press the Outbreak key or Scale key again to exit Outbreak mode.

POWER BUTTON

Press and hold for 1 second to turn on/off to enable the Thrusting and rotation functions.
Press the switch mode to turn the key light on and off. The default mode displays 0, and the digital tube displays the corresponding mode number. There are 8 modes.

0 To 9 Digits Displayed

Remove and clean the inner liner after use:

After using the product, remove the accessories in the following order for cleaning

- The object of cleaning is to remove the liner accessories, do not rinse the product cup body with water.



1. Turn the transparent shell to the right



2. Remove the transparent shell



4. Rinse or disinfect with water directly



3. Remove the inner liner from the transparent rack

Inner liner installation method:

After the product is cleaned and dried, install the parts in situ and store in a cool and dry place.

- Note: Do not break the liner during installation



1. Align the inner liner with the entrance of the transparent frame



2. The inner liner is installed in the transparent rack



4. Cover well



3. Turn the transparent shell to the left

Product Parameter

Product No: DB23-B261

Size: $\phi 88 \times 297 \text{mm}$

Material: Silicone+TPE+ABS

Rated Voltage: 3.7V

Battery Capacity: 1800mAh

Working Time: $\geq 45 \text{Min}$

Charging Time: $\leq 3 \text{H}$

Noise: $\leq 65 \text{DB}$

Function: 9 Kinds Thrusting, 9 Kinds Rotating

Weight: 520g

Color: Black

Waterproof: No

Enterprise standard: Q/DDB01-2017

Packing list: cup body*1/ USB cable*1/

Instruction book

Applicable: Adults over 18 years old

After-sale protection

If you have difficulty in using the process, please contact with our company, and we will do our best to bring you up For quality service. The quality assurance time of this product is one year from the purchase date, any product made or material The quality problems caused by defects are in the range of quality assurance. The freight charges incurred in the claim process shall be the provisions of this clause The supplement to consumer legal rights shall not affect any rights and interests of consumers

Matters need attention

The product contains rechargeable batteries, please don't use them in water or too wet, so as not to affect battery usage Life; When used, the motor can overheat because of the rapid rotation of the motor, which is not a quality question The topic; Prolonged use can produce a large amount of heat, which may cause a failure to run, and recommend no more than one time 30 minutes; Please keep it dry after cleaning, so as not to affect the life of the product